

LP	numer na mapie	Długość	Rura
Arkusz nr 1			
1	1	15,00	SRS160
2	2	15,00	SRS160
3	3	6,00	SRS160
4	4	6,00	SRS160
5	5	6,00	SRS160
6	6	6,00	SRS160
7	7	1,00	DVK160
8	8	1,00	DVK160
9	9	3,50	DVK160
10	10	3,50	DVK160
11	11	10,00	SRS160
12	12	10,00	SRS160
13	13	1,00	DVK160
14	14	1,00	DVK160
15	15	7,00	SRS160
16	16	3,00	DVK160
17	17	1,00	DVK160
18	18	10,00	SRS160
19	19	1,00	DVK160
20	20	1,00	DVK160
21	21	2,50	DVK160
22	22	9,50	SRS160
23	23	3,50	DVK160
24	24	4,00	DVK160
25	25	4,00	DVK160
26	26	6,00	DVK160
27	27	41,00	SRS200
28	27a	1,00	DVK160
29	28	2,50	DVK160
30	29	2,50	DVK160
31	30	8,00	SRS160
32	31	4,00	DVK160
33	32	15,00	SRS160
34	32a	1,00	DVK160
35	33	6,00	DVK160
36	34	10,00	DVK160
37	35	16,00	SRS160
38	36	7,00	SRS160
39	37	7,00	SRS160
40	37a	1,00	DVK160





